

DISINFECTION PROCEDURES AFTER INSTALLING UV LIGHT

- **PUT A ½ CUP OF CHLOROX AT LIGHT**
- **PULL TREATED WATER THRU ALL PIPES**
- **LET SET FOR 2 TO 3 HOURS**
- **RUN OFF UNTIL CHLORX IS NOT VISABLE**